


Warning: Steriflow Sanitary Regulators must only be used, installed and repaired in accordance with these Installation & Maintenance Instructions. Observe all applicable public and company codes and regulations. In the event of leakage or other malfunction, call a qualified service person; continued operation may cause system failure or a general hazard. Before servicing any valve, disconnect, shut off, or bypass all pressurized fluid. Before disassembling a valve, be sure to release all spring tension.

Please read these instructions carefully!

Your Steriflow/Jordan product will provide you with long, trouble-free service if it is correctly installed and maintained. Spending a few minutes now reading these instructions can save hours of trouble and downtime later. When making repairs, use only genuine Steriflow Valve parts, available for immediate shipment from the factory.

Ideal Installation



Preferred Installation

Caution! Installation of adequate overpressure protection is recommended to protect the regulator from overpressure and all downstream equipment from damage in the event of regulator failure.

1. An inlet block valve should always be installed.
2. If service application is continuous such that shut-down is not readily accomplished, it is recommended that an inlet block valve, outlet block valve, and a manual bypass valve be installed. Sanitary diaphragm or ball valves are usually recommended.
3. A sanitary outlet pressure gauge should be located

approximately ten pipe diameters downstream, and within sight. If you have ordered your JSRH with outlet gauge option on the valve outlet, please note that the outlet pressure as registered on the gauge may be slightly higher than a gauge located x diameters downstream, with the difference typically no more than 0.5 psig.

4. All installations should include a downstream relief device if the inlet pressure could exceed the pressure rating of any downstream equipment or the maximum outlet pressure rating of the unit.
5. Flow Direction: install so that the flow direction matches the inlet/outlet marking on the main regulator body (7).
6. For best performance, install in well drained horizontal pipe.
7. Basic regulator - (refer to Figure 2): regulator may be rotated around the pipe axis 360°. Recommended position is with knob (10) vertical upwards.
8. Regulators are not to be buried underground.
9. For insulated piping systems, recommendation is to not insulate regulator.

Principles of Operation

1. Movement occurs as pressure variations register on the diaphragm (4). The registering pressure is the outlet, P2, or downstream pressure. The range spring (3) opposes diaphragm (4) movement. As outlet pressure drops, the range spring (3) pushes the diaphragm (4) down, opening the port; as outlet pressure increases, the diaphragm (4) pushes up and the port opening closes.
2. A complete diaphragm (4) failure will cause the regulator to fail open.

Start Up

Caution! Don't not exceed the maximum rated pressure of the regulator if installed for a hydrostatic test. Isolate the unit if the test is above the valve rating. (Valve rating is 230 psi @ 100°F).

1. Start with the block valves closed. A bypass valve may be used to maintain outlet pressure in the

Distributed in the UK by:

Staitech Ltd • Unit 6 • Hope Mill Lane • Stroud • GL5 2SH • UK
+44 (0) 1453 882736 • sales@staitech.com • www.staitech.com

downstream system without changing the following steps.

2. Relax the range spring (3) by turning the adjusting knob (10) counter clockwise (CCW) until there is no noticeable spring tension.
3. If it is a "hot" piping system, and equipped with a bypass valve, slowly open the bypass valve to pre-heat the system piping and to allow slow expansion of the piping. Closely monitor outlet (downstream) pressure via gauge to ensure no over-pressurizing. Note: if no bypass valve is installed, extra caution should be used in starting up a cold system; i.e. do everything slowly.
4. Crack open the outlet (downstream) block valve.
5. Slowly open the inlet (upstream) block valve observing the outlet (downstream) pressure gauge. Determine if the regulator is flowing. If not, slowly rotate the regulator adjusting knob (10) clockwise (CW) until flow begins.
6. Continue to slowly open the inlet (upstream) block valve until fully open.
7. Continue to slowly open the outlet (downstream) block valve, especially when the downstream piping isn't pressurized. If the outlet (downstream) pressure exceeds the desired pressure, close the block valve and go to Step 2, then return to Step 4.
8. When flow is established steady enough that the outlet (downstream) block is fully open, begin to slowly close the bypass valve if installed.
9. Develop system flow to a level near its expected normal rate, and reset the regulator set point by turning the adjusting knob (10) CW to increase outlet pressure, or CCW to reduce outlet pressure.
10. Reduce system flow to a minimum level and observe set point. Outlet pressure will rise from the set point of Step 9.

Shutdown

1. On systems with a bypass valve, and where system pressure is to be maintained as the regulator is shut-down, slowly open the bypass valve while closing the inlet (upstream) block valve. (When on bypass, the system pressure must be constantly observed and manually regulated.) Close the outlet (downstream) block valve. CAUTION! Do not walk away and leave a bypassed regulator unattended.
2. If the regulator and system are to both be shut down, slowly close the inlet (upstream) block valve. Close the outlet (downstream) valve only if regulator removal is required.

Maintenance

Warning! System Under Pressure. Prior to performing any maintenance, isolate the regulator from the system

and relieve all pressure. Failure to do so could result in personal injury.

A. General

1. Maintenance procedures hereinafter are based upon removal of the regulator unit from the pipeline where installed.
2. Owner should refer to owner's procedures for removal, handling, cleaning and disposal of non-reuseable parts, i.e. gaskets, etc.
3. Refer to Figure 2 for basic regulator and Figure 1 for diaphragm subassembly.

B. Trim Replacement

Tool and materials required: adjustable wrench (medium size), 1" socket wrench, Krytox GPL 206, NSF H1 rated thread lubricant -anti seize compound. Use only parts supplied in a Steriflow Repair Kit.

1. Remove adjusting knob (10) by turning CCW until the threaded portion comes out of the spring housing (1).
2. If valve is removed from the line, place it in a vice, spring housing up.
3. Remove the spring housing (1), the upper spring guide (2), range spring (3), and diaphragm assembly (4, 5, & 6).
4. Remove the diffuser (13), diffuser seal (13), and soft seat (7).
5. Remove the plug (8) and the return spring (12).
6. Remove the old o-ring (11) from the plug (8) and replace it with a new one. Lubricate with Krytox GPL 206.
7. Place the new return spring (12) into the body, followed by the plug (8).
8. Place the new soft seat (9) into the main body bore.
9. Place the new diffuser seal (15) onto the diffuser (13). Coat the threads of the diffuser with Krytox GPL 206 and thread into the body hand tight. Using a torque wrench, tighten the diffuser to 200 in-lbs, taking care not to scratch the body.
10. Place the new diaphragm assembly (4, 5, & 6) from repair kit into the body. The larger diaphragm plate should be on top.
11. Place the range spring (3) on top of the diaphragm assembly, and the spring guide (2) on top of the range spring.
12. Replace the spring housing (1) after coating the threads with Krytox GPL 206. Tighten hand until the spring housing makes contact with the diaphragm. Tighten 45° past the contact point.
13. Replace the adjusting knob (10) by coating the threads with Krytox GPL 206 and threading it into the spring housing and turning CW.

C. Diaphragm Replacement

Caution! To prevent damage to body, use soft jaws when placing the body in a vise. Position so that vise closes over the flats on lower end of body.

1. Rotate the knob CCW until the knob assembly (10) comes out of the spring housing (1).
2. Place the valve body (7) in a vise clamping on the flats on the bottom of the body.
3. Remove spring housing (1) by grasping the flats with a wrench and turning (CCW).
4. Remove the diaphragm assembly (4, 5, & 6).
5. Disassemble the diaphragm subassembly (4, 5, & 6).
6. Clean all reusable parts according to owner's procedures.
7. Inspect and replace any necessary parts. NOTE: Use only parts manufactured and supplied by Steriflow Valve for these products.
8. Reassemble diaphragm assembly (4, 5, & 6) by placing the diaphragm (4) and upper diaphragm plate (6) over the threads of the lower diaphragm plate (5). Tighten the assembly until the diaphragm just starts to deform using a screwdriver in the slot of the lower diaphragm plate (5) and holding the upper diaphragm plate (6) in a vise.
9. Place diaphragm subassembly (4, 5, & 6) onto the body (7).
10. Place the range spring (3) on top of the diaphragm assembly (4, 5, & 6). Place the spring seat (2) on top of range spring (3).
11. Place the spring housing (1) over the spring seat (2) and range spring (3). Screw the spring housing (1) CW into the body (1). Tighten the spring housing (1) 45° past the contact point. Remove from vise.
12. Replace the adjusting screw assembly (10) into the spring housing (1) until range spring tension is felt.
13. Pressurize with air and spray liquid leak detector around body (7) and spring chamber (1) to test for leakage. Ensure that an outlet pressure is maintained during this leak test of at least mid-range spring level.

Troubleshooting


1. Erratic Operation; Chattering

- A. Oversize regulator; inadequate rangeability
 1. Check actuator flow conditions, re-size regulator for minimum and maximum flow.
 2. Increase flow rate.
 3. Decrease regulator pressure drop; decrease inlet pressure by placing a throttling orifice in inlet piping.
 4. Install next step higher range spring. Before replacing regulator, contact factory
- B. Worn poppet; inadequate guiding
 1. Replace trim (possible body replacement)
- C. Weakened/broken return spring.
 1. Determine if corrosion is causing. Replace return spring.

2. Regulator can't pass sufficient flow

- A. Regulator not closing tightly
 1. Inspect the seat of the plug sub-assembly, replace if worn.
- B. Downstream blockage
 1. Check system; isolate (block flow at regulator inlet - not outlet).
 2. Relocate regulator if necessary
- C. No pressure relief protection
 1. Install safety relief valve, or rupture disc.
- D. Restricted diaphragm movement
 1. Ensure no moisture in spring chamber at temperature below free point.

Cross Section View



Item No.	Description	Quantity
1	Spring Housing	1
2	Spring Seat	1
3	Range Spring	1
4	Diaphragm	1
5	Lower Diaphragm Plate	1
6	Upper Diaphragm Plate	1
7	Body	1
8	Plug	1
9	Seat	1
10	Adjusting Knob	1
11	O-Ring #010	1
12	Return Spring	1
13	Diffuser	1
14	Gasket	1